

GX-M Series

Options

INSTRUCTION MANUAL

GXM-04

GXM-06

COMPARATOR OUTPUT
ANALOG VOLTAGE OUTPUT

AND

A&D Company, Ltd.

© 2019 A&D Company Ltd. All rights reserved.

No part of this publication may be reproduced, transmitted, transcribed, or translated into any language in any form by any means without the written permission of A&D Company Ltd.

The contents of this manual and the specifications of the instrument covered by this manual are subject to change for improvement without notice.

Introduction

| | | |
|------|---|----|
| 1. | Introduction | 4 |
| 2. | Features..... | 4 |
| 3. | Packing List | 5 |
| 4. | Installing the Option..... | 5 |
| 5. | Function Table of Balance | 7 |
| 5.1. | Operation Keys and Display of Function Table | 7 |
| 5.2. | Items List of the Function Table | 8 |
| 6. | GXM-04 Comparator Output..... | 11 |
| 6.1. | Specifications of comparator Output..... | 11 |
| 6.2. | Using the Comparator Output | 13 |
| 6.3. | Comparison Method Selection (Tolerance Range and Center Value or Threshold Values) .. | 14 |
| 6.4. | Setting Threshold Values | 15 |
| 6.5. | Setting Center Value and Tolerance Range | 17 |
| 7. | GXM-06 Analog Voltage Output | 19 |
| 7.1. | Specifications of Analog Voltage Output..... | 19 |
| 7.2. | Function Table of Analog Voltage Output..... | 20 |
| 7.3. | Voltage Output Selection | 22 |
| 7.4. | Voltage Output Fine Adjustment..... | 22 |
| 7.5. | Fixed Voltage Output..... | 23 |

1. Introduction

This manual describes how the GXM-04, GXM-06 (Comparator output, analog voltage output) works and how to get the most out of it in terms of performance. Read this manual thoroughly before using and keep it at hand for future reference.

2. Features

The following options can be used for the GX-M series and GF-M series.

- GXM-04 Comparator output (with buzzer) / External contact input x 2 / RS-232C
- GXM-06 Analog voltage output / RS-232C






GXM-04: Comparator output / External contact input

- The GXM-04 can compare the weighing value and preset threshold values and can output the result to the contact output.
- The GXM-04 is equipped with six contact outputs: "HH", "HI", "OK", "LO", "LL" of the comparison output and "READY" output to indicate the status of the balance.
3-stage comparison or 5-stage comparison can be selected.
- The GXM-04 can sound a buzzer according to the comparison result.
- The GXM-04 is equipped with external control input terminals that can make the RE-ZERO and PRINT key operations. An optional foot switch (AX-SW137-PRINT, AX-SW137-RE-ZERO) can be used.

GXM-06: Analog voltage output

- The GXM-06 can output analog voltage in the following modes :
"mode where the specified digits of the weighing value are converted to voltage" and
"mode where weighing value is converted to voltage in range between gross zero or net zero and full scale".
- The voltage output range can be selected using the "0V~/0.2V~" switch on the panel.
It can be selected "0 to 1V" range and "0.2V to 1V" range. The factory setting is "0 to 1V" range.

3. Packing List

| | | | |
|--------------|----------------------------------|---|---|
| GXM-04 | Mini DIN connector (8 pin, plug) | 1 |  |
| | Cable with connector (AX-KO5692) | 1 |  |
| | This manual | 1 | |
| | | | |
| GXA-06 | Screwdriver for adjustment | 1 |  |
| | Mini DIN connector (4 pin, plug) | 1 |  |
| | Cable with connector (AX-KO5692) | 1 |  |
| | This manual | 1 | |

4. Installing the Option


Caution Disconnect the AC adaptor before installing the option to the balance.

Installing the option board to the balance

Install the GXM-04 and GXM-06 according to the following procedure.
(The installation procedure of the GXM-04 and GXM-06 is the same.)


Step1 Remove the two screws from the panel and remove the RS-232C / USB board from the balance.

Step2 Pull gently and remove the two cables from the RS-232C / USB board.



Step3 Insert the two cables into the sockets of the GXM-06 board.

Step4 Insert the rubber packing and plug the GXM-06 into the balance.
Screw the panel of GXM-06.




Caution

- When inserting the GXM-06, pay attention to the top and bottom orientation of the board.
- The rubber packing has a deep groove on the balance side.

Assembling the mini-DIN connector

- Step1 Pass the cable through the rubber sleeve.
- Step2 Solder wires and terminal.
- Step3 Cover the terminal with the top metal case and bottom metal case.
- Step4 Fasten wires with the top metal case.
- Step5 Insert the assembled parts into the rubber sleeve.




5. Function Table of Balance

The function table stores parameters that specify how to operate the balance, and it is used to monitor or update those parameters. These parameters are stored in memory even if the AC adaptor is removed and are retained until overwritten. Balance operations are specified by this table when using the GXA-04 and GXA-06. The table menu consists of two layers as shown in the diagram below. The first layer is the "Class" and the second layer is the "Item". Each item stores a "parameter". The last displayed parameter is in effect. After the

PRINT key is pressed, these updated parameters are applied to operations of the balance.

Example of settings and menu structure

Example : Set to "Center value using sample weight input" of "Input method" in "Comparator".



Caution

The balance may not function properly, depending on the settings and the operating environment. Be sure to set parameters correctly.

5.1. Operation Keys and Display of Function Table

| | |
|------------------|--|
| ○ | The ○ indicates that the parameter displayed is in effect. |
| 1/10d SAMPLE | Enters the function table when pressed and held in the weighing mode. Selects the class or item in the function table. |
| →0/T← RE-ZERO | Changes the parameter. |
| PRINT | Moves to an item in the class when a class is displayed. Stores the new parameter and displays the next class when an item is displayed. |
| CAL | Cancels new parameter and displays the next class when an item is displayed. Exits the function table and returns to the weighing mode when a class is displayed. |

5.2. Items List of the Function Table

Note Functions available differ by model of the balance.

| Class | Item | Parameter | Description | |
|---|------------------------------------|-----------|---|---|
| <i>bRSFnc</i> Environment·display | | | (Refer to the instruction manual of main unit) | |
| <i>[L AdJ]</i> Clock adjustment | | | | |
| <i>[P Fnc]</i> Comparator | <i>[P]</i> Comparator mode | ■ 0 | No comparison (Comparator is not used) | |
| | | 1 | Comparison when stable value or overloaded | |
| | | 2 | Comparison always | |
| | <i>[P-t]</i> Comparator method | ■ 0 | 3-stage comparison | [HI] , [OK] , [LO] |
| | | 1 | 5-stage comparison | [HH] , [HI] , [OK] , [LO] , [LI] |
| | <i>[P-z]</i> Zero near | 0 | Comparison including near zero | |
| | | 1 | Comparison excluding | ±5 digits (counts) from zero |
| | | ■ 2 | Comparison excluding | ±10 digits (counts) from zero |
| | | 3 | Comparison excluding | ±20 digits (counts) from zero |
| | | 4 | Comparison excluding | ±50 digits (counts) from zero |
| | <i>[P-p]</i> Polarity | 0 | Comparison of positive values only | |
| | | 1 | Comparison of negative values only | |
| | | ■ 2 | Comparison of both polarities | |
| | <i>[P-r]</i> Comparison results | ■ 1 | Not added | Select whether or not to add the comparison results to the output data. |
| | | 2 | Added | |
| | <i>[P in]</i> Input method | ■ 0 | Threshold value using numerical input [P HH] , [P H1] , [P L0] and | |
| | | 1 | Threshold value using sample weight [P LL] are used | |
| | | 2 | Center value using numerical input [P rEF] , [P LHE] and | |
| | | 3 | Center value using sample weight [P LHE2] are used | |
| | <i>[P-Frd]</i> Flow measurement | ■ 0 | Comparison by flow rate value | |
| | | 1 | Comparison by weighing value (g) | |
| <i>[P-b]</i> Main display comparison | ■ 0 | OFF | Displays the results on the main portion of the display in place of the weight value. | |
| | 1 | ON | | |


| Class | Item | Parameter | Description |
|--|---|----------------------------|--|
| [P VALUE Comparator threshold value | [P HH Second upper limit | [P HH], [P LL] | Refer to explanation of "6. GXM-04 Comparator output". Upper / lower limits when using the data input method ([P in] [0] or [P in] [1]) is selected. [P HH], [P LL] are displayed when 5-stage comparison ([P-t] [1]) is selected. |
| | [P H, Upper limit | | |
| | [P Lo Lower limit | | |
| | [P LL Second lower limit | [P rEF], [P LMt], [P LMt2] | Refer to explanation of "6. GXM-04 Comparator output". Reference value when using the data input method ([P in] [2] or [P in] [3]) is selected. [P LMt2] is displayed when 5-stage comparison ([P-t] [1]) is selected. |
| | [P rEF Center value | | |
| | [P LMt Tolerance range from center value | | |
| | [P LMt2 Second tolerance range from center value | | |

- indicates factory settings. Digit is the unit of minimum division (readability).

| Class | Item | Parameter | Description | | |
|--|--|--|------------------------------|--|--|
| [P] bEEP Comparator buzzer | bEP HH HH buzzer | ■ 0 | Off | Displayed only when 5-stage comparison ([P-t] [I]) is selected. | |
| | | 1 | On | | |
| | bEP H, Hi buzzer | ■ 0 | Off | | |
| | | 1 | On | | |
| | bEP OK OK buzzer | ■ 0 | Off | | |
| | | 1 | On | | |
| | bEP Lo Lo buzzer | ■ 0 | Off | | |
| | | 1 | On | | |
| | bEP LL LL buzzer | ■ 0 | Off | Displayed only when 5-stage comparison ([P-t] [I]) is selected. | |
| | | 1 | On | | |
| | dout Data output | (Refer to instruction manual of main unit) | | | |
| | S, F Serial interface | | | | |
| USB USB interface | | | | | |
| Rout Analog output | An Analog output mode | ■ 0 | 2-digit output mode | Displayed only when the GXM-06 is connected. | |
| | | 1 | 3-digit output mode | | |
| | | 2 | Net full scale output mode | | |
| | | 3 | Gross full scale output mode | | |
| | SEL Output digit selection | ■ 0 | First digit | Displayed only when the GXM-06 is connected. | |
| | | 1 | Second digit | | |
| | | 2 | Third digit | | |
| | | 3 | 4th digit | | |
| | | 4 | 5th digit | | |
| | | 5 | 6th digit | | |
| | | 6 | 7th digit | | |
| | AP Fnc Application | (Refer to instruction manual of main unit) | | | |
| | MW Fnc Alarm function for minimum weighing value | | | | |
| | Unit Unit | | | | |
| dS Fnc Density function | | | | | |
| ID ID number | | | | | |
| PASSwd Password lock | | | | | |
| Ruto [AL] ※ Automatic calibration | | | | | |
| [S in] ※ Internal mass value correction | (Refer to instruction manual of main unit) | | | | |

■ indicates factory settings. ※ : Settings for GX-A series.

Optional foot switch can connect to either input.



Using External Contact Input

When 1 pin and 3 pin or 1 pin and 2 pin of lead wire of optional foot switch (AX-SW137-PRINT, AX-SW137-RE-ZERO) is shorted 100 ms or longer, it can be operated the same as the **PRINT** key and **RE-ZERO** key on the panel.

6.2. Using the Comparator Output

This option can output results of the 3-stage comparison or 5-stage comparison that is specified at "Comparison method ([P-t])" in the function table of the balance.

Comparison results are displayed using [HI], [OK], [LO] and are output using contacts of I/O terminals. Comparison tolerance ranges are the following 3 types and they can be specified at "Comparator mode ([P])" in the function table.

"No comparison", "Comparison when stable value or overloaded", or "Comparison always"

The range of near zero can is specified at "Near zero ([P-z])" in the function table.

There are two types of comparison method. One is the method using second upper limit, upper limit, lower limit and second lower limit. Another is the method using center value and tolerance range. There two types of input methods for second upper limit, upper limit, lower limit and second lower limit. One is the numerical input. Another is the input using sample weight.

Balance can sound a buzzer according to the comparison result. That can be specified at "Comparator buzzer ([P bEEP])" in the function table.

When weighing value is not displayed in performing RE-ZERO, etc., READY contact becomes "open". When weighing value is displayed, READY contact becomes "short".

3-stage comparison result 3-stage comparison – display, contact output

| Weighing value Threshold value Formula | Result | Display | Contact output | | | Buzzer |
|--|--------|--------------------|----------------|-------|-------|---------|
| | | | HI | OK | LO | |
| UL $UL < WV$ | HI | [HI] illuminated | Short | | Open | bEEP HI |
| LL $LL \leq WV \leq UL$ | OK | [OK] illuminated | | Short | | bEEP OK |
| $WV < LL$ | LO | [LO] illuminated | Open | | Short | bEEP LO |

Weighing value: WV, Upper limit: UL, Lower limit: LL

5-stage comparison result 5-stage comparison – display, contact output

| Weighing value Threshold value Formula | Result | Display | Contact output | | | | | Buzzer |
|--|--------|--------------------|----------------|-------|-------|-------|-------|---------|
| | | | HH | HI | OK | LO | LL | |
| SUL $SUL < WV$ | HH | [HI] blinking | Short | | | | | bEEP HH |
| UL $UL < WV \leq SUL$ | HI | [HI] illuminated | | Short | | Open | | bEEP HI |
| LL $LL \leq WV \leq UL$ | OK | [OK] illuminated | | | Short | | | bEEP OK |
| SLL $SLL \leq WV < LL$ | LO | [LO] illuminated | | Open | | Short | | bEEP LO |
| $WV < SLL$ | LL | [LO] blinking | | | | | Short | bEEP LL |

Weighing value: WV, Second upper limit: SUL, Upper limit: UL, Lower limit: LL, Second lower limit: SLL

6.3. Comparison Method Selection (Tolerance Range and Center Value or Threshold Values)

Setting Example

| | | | |
|---|--------|-----|-----------------|
| Comparison always | [P] | [2] | |
| 5-stage comparison | [P-t] | [1] | |
| Comparison excluding ±5 digits (counts) from zero | [P-Z] | [1] | |
| Comparison of both polarities | [P-P] | [2] | Factory setting |
| Center value using numerical input | [P in] | [2] | or |
| Center value using sample weight | [P in] | [3] | |

Procedure

Step 1 Press and hold the **SAMPLE** key to enter the function table.

bASFnC is displayed.

Step 2 Press the **SAMPLE** key to display **[P F nC]** (Comparator).

Step 3 Press the **PRINT** key to enter **[P F nC]** (Comparator).

Step 4 Press the **RE-ZERO** key several times to display **[P 2]** (Comparison always).

Step 5 Press the **SAMPLE** key to display **[P-t]** (Comparison method).

Step 6 Press the **RE-ZERO** key to display **[P-t 1]** (5-stage comparison).

Step 7 Press the **SAMPLE** key to display **[P-Z]** (Near zero).

Step 8 Press the **RE-ZERO** key several times to display **[P-Z 1]** (Comparison excluding ±5 digits (counts) from zero).


Step 9 Press the **SAMPLE** key several times to display **[P in]** (Input method).

Step 10 Press the **RE-ZERO** key several times to select input method.

[P in 2] (Center value using numerical input) or,

[P in 3] (Center value using sample weight)

Step 11 Press the **PRINT** key to store new settings and use them.



6.4. Setting Threshold Values

This explanation uses $\boxed{[P-t]}$ $\boxed{1}$ (5-stage comparison) and specifies $\boxed{[P, n]}$ $\boxed{0}$ (Threshold value using numerical input) or $\boxed{[P, n]}$ $\boxed{1}$ (Threshold value using sample weight) to $\boxed{[P, n]}$ (input method) in the function table and inputs the threshold value.

Selecting a input method

(If $\boxed{[P, n]}$ $\boxed{0}$ or $\boxed{1}$)

Step 1 Press and hold the $\boxed{\text{SAMPLE}}$ key to enter the function table. $\boxed{\text{bASSFC}}$ is displayed.

Step 2 Press the $\boxed{\text{SAMPLE}}$ key several times to display $\boxed{[P VALUE]}$ (Comparator threshold value).

Step 3 Press the $\boxed{\text{PRINT}}$ key to enter $\boxed{[P VALUE]}$ (Comparator threshold value).

Step 4 Press the $\boxed{\text{SAMPLE}}$ key several times to input threshold value. Refer to the following "Threshold value using numerical input" or "Threshold value using sample weight".

Step 5 If the $\boxed{\text{PRINT}}$ key is pressed when threshold value is displayed, the current parameters are displayed (all digits blinks).

Numerical input of threshold values

(If $\boxed{[P, n]}$ $\boxed{0}$)

Step 6 If changing the parameters, press the $\boxed{\text{RE-ZERO}}$ key to store the following keys.

| | |
|------------------------------|----------------------------------|
| $\boxed{\text{SAMPLE}}$ key | Moves blinking digit. |
| $\boxed{\text{RE-ZERO}}$ key | Changes value of blinking digit. |
| $\boxed{\text{MODE}}$ key | Changes polarity. |
| $\boxed{\text{PRINT}}$ key | Stores and proceeds to step 7. |
| $\boxed{\text{CAL}}$ key | Cancels and proceeds to step 7. |

If the current parameters will be maintained, press the $\boxed{\text{PRINT}}$ or $\boxed{\text{CAL}}$ key to proceed to step 7.

Step 7 Repeat step 4, 5 and 6 for other threshold values.

Storing threshold values using sample weight

(If $\boxed{[P, n]}$ $\boxed{1}$)

Step 8 Press the $\boxed{\text{RE-ZERO}}$ key to display $\boxed{0.00 g}$.

Put the sample on the weighing pan and press the $\boxed{\text{PRINT}}$ key to store weighing value as the threshold value.

| | |
|------------------------------|---|
| $\boxed{\text{RE-ZERO}}$ key | Resets display of the balance to zero. |
| $\boxed{\text{PRINT}}$ key | Stores weighing value and proceeds to step 9. |

Step 9 Repeat step 4, 5 and 6 for other threshold values.

Storing threshold values using RS-232C commands from peripherals

The second upper limit, upper limit, lower limit and second lower limit can be specified using RS-232C commands from peripherals.

| | | |
|-----------------|--------------------|--------------------|
| Example command | HH: +1000.000 _ _g | second upper limit |
| | HI: +0800.000 _ _g | upper limit |
| | LO: +0600.000 _ _g | lower limit |
| | LL: +0400.000 _ _g | second lower limit |

_ : space of ASCII code 20 h

6.5. Setting Center Value and Tolerance Range

This explanation uses $\boxed{[P-t] \boxed{1}}$ (5-stage comparison), specifies $\boxed{[P, n] \boxed{2}}$ (Center value using numerical input) or $\boxed{[P, n] \boxed{3}}$ (Center value using sample weight input) to $\boxed{[P, n]}$ (input method) in the function table, and compares using the center value and numerical input of tolerance range.

Selecting a input method

(If $\boxed{[P, n] \boxed{2}}$ or $\boxed{3}$)

Step 1 Press and hold the $\boxed{\text{SAMPLE}}$ key to enter the function table.

\boxed{bRSFnC} is displayed.

Step 2 Press the $\boxed{\text{SAMPLE}}$ key several times to display $\boxed{[P \text{ VALUE}]}$ (comparator threshold value).

Step 3 Press the $\boxed{\text{PRINT}}$ key to display $\boxed{[P \text{ VALUE}]}$ (comparator threshold value).

Step 4 Press the $\boxed{\text{SAMPLE}}$ key several times to display "Center value using numerical input" or "Center value using sample weight". Specify the center value, tolerance range and second tolerance range.

Numerical input of center value

(If $\boxed{[P, n] \boxed{2}}$)

Step 5 Press the $\boxed{\text{PRINT}}$ key while displaying $\boxed{[P rEF]}$. The current parameter is displayed (all digits blinking). If parameter does not need to be changed, press the $\boxed{\text{PRINT}}$ key or $\boxed{\text{CAL}}$ key and proceed to step 6. If the parameter is to be changed, press the $\boxed{\text{RE-ZERO}}$ key and change it using the following keys.

| | |
|------------------------------|----------------------------------|
| $\boxed{\text{SAMPLE}}$ key | Moves blinking digit. |
| $\boxed{\text{RE-ZERO}}$ key | Changes value of blinking digit. |
| $\boxed{\text{MODE}}$ key | Changes polarity. |
| $\boxed{\text{PRINT}}$ key | Stores and proceeds to step 6. |
| $\boxed{\text{CAL}}$ key | Cancels and proceeds to step 6. |

Step 6 Proceed to "Storing tolerance range from center value using numerical input".

Storing center value using sample weight

(If $\boxed{[P, n] \boxed{3}}$)

Step 7 Press the $\boxed{\text{PRINT}}$ key while displaying $\boxed{[P rEF]}$. The current parameter is displayed (all digits blinks). Press the $\boxed{\text{RE-ZERO}}$ key to enter to the sample weight input mode. Press the $\boxed{\text{RE-ZERO}}$ key to display $\boxed{0.00 \text{ g}}$. Put sample of center value on the pan and press the $\boxed{\text{PRINT}}$ key. The current parameter can be confirmed (all digits blinking). Press the $\boxed{\text{PRINT}}$ key to store the center value.

Step 8 Next, $\boxed{[P LME]}$ is displayed.

Step 9 Proceed to "Storing tolerance range from center value using numerical input".

Storing tolerance range from center value using numerical input

Step 10 Press the **PRINT** key while displaying **[P L M E]**. The current parameter is displayed.

If the tolerance range is to be changed, change it using the following keys.

Input the tolerance range with center value assumed to be 100%.

| | |
|--------------------|----------------------------------|
| SAMPLE key | Moves blinking digit. |
| RE-ZERO key | Changes value of blinking digit. |
| PRINT key | Stores and proceeds to step 11. |
| CAL key | Cancels and proceeds to step 11. |

Step 11 Press the **PRINT** key while displaying **[P L M E ?]**. The current parameter is displayed.

If the second tolerance range is to be changed, change it using the following keys.

Input the second tolerance range with center value assumed to be 100%.

| | |
|--------------------|----------------------------------|
| SAMPLE key | Moves blinking digit. |
| RE-ZERO key | Changes value of blinking digit. |
| PRINT key | Stores and proceeds to step 12. |
| CAL key | Cancels and proceeds to step 12. |

Step 12 Press the **CAL** key to return to weighing mode. GXM-06 Analog Voltage Output

The analog voltage output (GXM-04) can convert the specified weighing value to analog voltage between 0 and 1 V and output it.

7. GXM-06 Analog Voltage Output


The analog voltage output (GXM-06) can convert the specified weighing value to analog voltage between 0 and 1 V and output it.

7.1. Specifications of Analog Voltage Output

Analog Voltage Output


| | | |
|---|------------------|--|
| Output impedance | 100 Ω or less | |
| Linearity | ±0.3% or less | |
| Output connector | Compatible plug: | 4 pin mini DIN connector [Female] (Accessory) E4-200J-100 or equivalent |
| Pin connections | Output | 4 pin |
| | GND | 3 pin |
| Output range | 0 V to 1 V | With the slide switch set to "0V~" |
| | 0.2 V to 1 V | With the slide switch set to "0.2V~" |
| Input impedance of the device connected | 10 kΩ or greater | |

Panel External View




Analog voltage output

Output circuit



Pin assignments and wire colors of accessory cable

| Pin No. | Description | Wire color |
|---------|-----------------------|------------|
| 1 | N.C. No connection | Black |
| 2 | N.C. No connection | Blue |
| 3 | Analog GND (0V) | Red |
| 4 | Analog voltage output | White |
| Housing | Case | Shield |



7.2. Function Table of Analog Voltage Output


R_{out} of the function table can be selected when this option is connected.

R_{out} Analog output

| Item | Parameter | Description |
|------------------------------------|--------------------------------------|--|
| R_n Analog output mode | ■0 | 2-digit output mode Converts 2 consecutive digits with minimum digit selected by SEL to voltage. |
| | 1 | 3-digit output mode Converts 3 consecutive digits with minimum digit selected by SEL to voltage. |
| | 2 | Net full scale output mode Outputs 0.000 V when the net weight is zero. Outputs 1.000 V when the net weight is full scale. Output is 0.000 V when zero is set using the $RE-ZERO$ key. |
| | 3 | Gross full scale output mode Outputs 0.000 V when the gross weight is zero. Outputs 1.000 V when the gross weight is full scale. Tare operation using the $RE-ZERO$ key will not affect the output. (Note: If tare is extremely light, tare operation might change the zero point. Thus affecting the output.) |
| SEL Output digit selection | | Specify minimum digit to be output at R_n mode. When R_n is set to 0 or 1, the setting is in effect. |
| | ■0 | Specify first digit as minimum digits. |
| | 1 | Specify second digit as minimum digits. |
| | 2 | Specify third digit as minimum digits. |
| | 3 | Specify 4th digit as minimum digits. |
| | 4 | Specify 5th digit as minimum digits. |
| | 5 | Specify 6th digit as minimum digits. |
| 6 | Specify 7th digit as minimum digits. | |


- indicates factory settings.

Example



Caution The hidden high-order digits are regarded as zero.

The hidden least significant digit is regarded as zero (when the least significant digit is hidden using the **SAMPLE** key).



If $R_n 2$ or $R_n 3$

| Model | | | | Full scale |
|-----------|------------|-----------|------------|------------|
| GX-8202M | GX-8202MD | GF-8202M | GF-8202MD | 8 kg |
| GX-10202M | | GF-10202M | | 10 kg |
| GX-12001M | | GF-12001M | | 12 kg |
| GX-22001M | | GF-22001M | | 22 kg |
| GX-32001M | GX-32001MD | GF-32001M | GF-32001MD | 32 kg |

Example When the GX-10202M displays 1 kg, the voltage output of $R_n 2$ is 0.1 V.

(Using "0V~" of the slide switch)

$$1.000V \times \frac{1 \text{ kg}}{10 \text{ kg}} = 0.100V$$

Caution "Full scale" of the full scale output mode indicates the full scale values shown in the tables above. The output voltage may exceed 1.000 V, depending on the weighing value.

Example When the GX-10202M displays 10.2 kg, the voltage output is 1.02 V.

(Using "0V~" of the slide switch)

$$1.000V \times \frac{10.2 \text{ kg}}{10 \text{ kg}} = 1.02V$$


7.3. Voltage Output Selection

The range of output voltage can be change using the slide switch on the panel.

Factory settings is "0V ~".

- "0V~" (0 to 1 V) : Zero 0.000 V, full scale 1.000 V
- "0.2V~" (0.2 to 1 V) : Zero 0.200 V, full scale 1.000 V


Panel External View



7.4. Voltage Output Fine Adjustment

The voltage output has been adjusted at the factory before shipment.

Using the ZERO volume and SPAN for fine adjustment and a voltmeter, voltage output can be finely adjusted.



Procedure

Step 1 Turn off the display using the **ON:OFF** key.

Voltage output becomes zero point status.

Adjust the ZERO volume so that the voltmeter indicates 0.000 V (when the slide switch is set to "0V~").


Adjust the ZERO volume so that the voltmeter indicates 0.200 V (when the slide switch is set to "0.2V~").

The display to output 0 V (0.2 V).



Step 2 While pressing and holding the **PRINT** and **SAMPLE** keys, press the **ON:OFF** key to enter the initializing mode. Then 1 V is output. Adjust the SPAN volume so that the voltmeter indicates 1.000 V

The display to output 1 V.



Step 3 Repeat step 1 and step 2 until the correct voltage output is obtained.

7.5. Fixed Voltage Output

The voltage output is fixed under the following conditions:

- Step 1 With the display off, 0 V is output (or 0.2 V if the slide switch is set to "0.2V~") when not weighing during calibration, etc.
- Step 2 During the re-zeroing operation in gross full scale output mode ($\boxed{R_n} \boxed{3}$), the previous output value is retained.
 During the re-zeroing operation in 2-digit output mode ($\boxed{R_n} \boxed{0}$), 0 V is output (or 0.2 V if the slide switch is set to "0.2V~").
 During the re-zeroing operation in 3-digit output mode ($\boxed{R_n} \boxed{1}$), 0 V is output (or 0.2 V if the slide switch is set to "0.2V~").
- Step 3 When $\boxed{-E}$ (weighing value is negative overload) is displayed, 0 V is output (or 0.2 V if the slide switch is set to "0.2V~").
- Step 4 When \boxed{E} (weighing value is positive overload) is displayed, the following voltages are output.

Example Voltage output when \boxed{E} is displayed if the slide switch is set to "0V~".

| Model | | | | $\boxed{R_n} \boxed{0}$ 、 | $\boxed{R_n} \boxed{2}$ 、 |
|-----------|------------|-----------|------------|---------------------------|---------------------------|
| | | | | $\boxed{R_n} \boxed{1}$ | $\boxed{R_n} \boxed{3}$ |
| GX-8202M | GX-8202MD | GF-8202M | GF-8202MD | 1.000 V | 1.025 V |
| GX-10202M | | GF-10202M | | 1.000 V | 1.02 V |
| GX-12001M | | GF-12001M | | 1.000 V | 1.017 V |
| GX-22001M | | GF-22001M | | 1.000 V | 1.009 V |
| GX-32001M | GX-32001MD | GF-32001M | GF-32001MD | 1.000 V | 1.006 V |



A&D Company, Limited

3-23-14 Higashi-Ikebukuro, Toshima-ku, Tokyo 170-0013, JAPAN
Telephone: [81] (3) 5391-6132 Fax: [81] (3) 5391-1566

A&D ENGINEERING, INC.

1756 Automation Parkway, San Jose, California 95131, U.S.A.
Telephone: [1] (408) 263-5333 Fax: [1] (408) 263-0119

A&D INSTRUMENTS LIMITED

Unit 24/26 Blacklands Way, Abingdon Business Park, Abingdon, Oxfordshire OX14 1DY United Kingdom
Telephone: [44] (1235) 550420 Fax: [44] (1235) 550485

A&D AUSTRALASIA PTY LTD

32 Dew Street, Thebarton, South Australia 5031, AUSTRALIA
Telephone: [61] (8) 8301-8100 Fax: [61] (8) 8352-7409

A&D KOREA Limited

한국에이.엔.디(주)
서울특별시 영등포구 국제금융로6길33 (여의도동) 맨하탄빌딩 817 우편 번호 07331
(817, Manhattan Bldg., 33. Gukjegeumyung-ro 6-gil, Yeongdeungpo-gu, Seoul, 07331 Korea)
전화: [82] (2) 780-4101 팩스: [82] (2) 782-4264

ООО A&D RUS

ООО "ЭЙ энд ДИ РУС"
121357, Российская Федерация, г.Москва, ул. Верейская, дом 17
(Business-Center "Vereyskaya Plaza-2" 121357, Russian Federation, Moscow, Vereyskaya Street 17)
тел.: [7] (495) 937-33-44 факс: [7] (495) 937-55-66

A&D INSTRUMENTS INDIA PRIVATE LIMITED

ऐ&डी इन्स्ट्रूमेन्ट्स इण्डिया प्रा० लिमिटेड
509, उद्योग विहार , फेस -5, गुडगांव - 122016, हरियाणा , भारत
(509, Udyog Vihar, Phase-V, Gurgaon - 122 016, Haryana, India)
फोन : 91-124-4715555 फैक्स : 91-124-4715599