

HW-D-C / HW-D-CP

Platform Scale Indicator

INSTRUCTION MANUAL

1WMPD4005548A



Warning Definition

The warnings described in this manual have the following meanings:



DANGER Indicates a hazardous situation which, if not avoided, will result in death or serious injury.



Note Information or cautions to use the device correctly.



This is a safety alert symbol.

About This Manual

- (1) No part of this manual may be reprinted, copied, modified, or translated to another language without the prior written consent of A&D Company, Limited (A&D).
- (2) The contents of this manual are subject to change without notice.
- (3) Please contact A&D if you notice any uncertainty, errors, omissions, etc. in this manual.
- (4) A&D bears no liability for any loss or lost profits due to the operation of this product, and for direct, indirect, special, or consequential damages resulting from any defect in this product or this manual, even if advised of the possibility of such damage. Furthermore, A&D assumes no liability for claims of rights from third parties. Concurrently, A&D assumes no liability whatsoever for software or data losses.

© 2025 A&D Company, Limited

- ❑ The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by A&D is under license.
- ❑ Other product names and company names mentioned in this manual are trademarks or registered trademarks of their respective companies in Japan or other countries and regions.

Contents

1. Compliance	4
1.1. Compliance with FCC Rules	4
2. Introduction	4
3. Features	4
4. Included Items	5
4.1. Installing the Batteries for Type C	6
5. Cautions	7
5.1. Precautions for Installing the Indicator	7
5.2. Load Cell Connection	8
5.3. How to Connect the Load Cell	10
5.4. Verifying Load Cell Output and Input Sensitivity	11
5.5. Setting Up the Indicator	12
5.6. Sensitivity Adjustment and Parameter Settings	12
6. Part Names	13
6.1. Display and Symbols	14
6.2. Description of Keys	15
7. Sensitivity Adjustment	17
7.1. Sensitivity Adjustment Items	17
7.2. Setting of the Weighing Capacity / Minimum Division / Decimal Point Position	19
7.3. Sensitivity Adjustment Using a Weight	20
7.4. Correcting for Gravitational Acceleration	21
8. Setting Functions	22
8.1. Setting of the CF Function	22
8.2. CF Function List	23
9. Options	25
9.1. Installing Options	25
10. Maintenance	26
10.1. Repair	26
10.2. Error Display	26
10.3. Error Code Table	27
11. Specifications	27
11.1. Specifications List	27
11.2. Dimensions	28
11.3. Gravity Acceleration Map	29

1. Compliance

1.1. Compliance with FCC Rules

This device contains transmitter module FCC ID: 2A6NFEC2832

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. (FCC = Federal Communications Commission in the U.S.A.)

FCC CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The antenna used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This product is certified as type of the portable device with FCC Rules. To maintain compliance with RF Exposure requirement, please use within specification of this product.

2. Introduction

Thank you for purchasing the HW-D-C/CP platform scale indicator from A&D. This instruction manual mainly describes how to install the HW-D-C/CP. Refer to it when connecting/installing the HW-D-C/CP to a weighing platform (load cell). The HW-D-C/CP has functionality comparable with the display of the HV-C/CP and HW-C/CP series of digital platform scales. Some functions and operations are described in this manual. Other information is found in the instruction manual indicated below.

[Instruction manual for the HV-C/CP and HW-C/CP series]

(<https://aandd.jp/products/weighing/scale/platform/hvw-ccp.html>)

Refer to the above manual in order to understand the HV-C/CP and HW-C/CP series of digital platform scales and how to use them properly. The manual can be downloaded from the A&D website <https://www.aandd.jp>.





3. Features

The HW-D-C / CP is an electronic indicator that is appropriate for composing a digital platform scale by connecting to a weighing platform (load cell), and it has the following features.

- Operating up to four 350 Ω load cells is available.
- Available range selection, for the display resolution, is 1/20 to 1/60,000.
- Minimum division can be selected from 1 g, 2 g and 5 g.
- The weighing capacity can be freely set between 100 and 300,000 (within 1/60,000 display resolution).
- Available weighing units are kg (kilogram), lb (pound), oz (ounce), and pcs (pieces for the counting mode).
- Functionality is comparable with the display of the HV-C / CP and HW-C / CP series.

4. Included Items

The product includes the following items.

HW-D-C	HW-D-CP (for built-in printer models)
<ul style="list-style-type: none"> ● Main Unit <p>Model label</p>  <p>Affixed here</p>  <p>Write the capacity and section here.</p> 	<ul style="list-style-type: none"> ● Main Unit <p>Model label</p>  <p>Affixed here</p>  <p>Write the capacity and section here.</p>
<ul style="list-style-type: none"> ● Quick Start Guide 	<ul style="list-style-type: none"> ● Quick Start Guide ● Dedicated roll paper  
<ul style="list-style-type: none"> ● AC adapter   <p>(may differ from actual item)</p>	<ul style="list-style-type: none"> ● AC adapter   <p>(may differ from actual item)</p>



AC Adapter

Confirm that the AC adapter matches the voltage and plug type of your region. An AC adapter is not provided in some regions.

4.1. Installing the Batteries for Type C

Step 1 Turn off the display.
Remove the AC adapter.


⚠ AC adapter

Please confirm that the AC adapter type is correct for your local voltage and receptacle type. The AC adapter may not be provided for some areas.


Step 2 Open the battery cover and inner cover in that order.
Push the battery cover and slide it.
Push the hook of the inner cover to the left and lift it.

Step 3 Insert four new batteries with proper polarity (+,-).
Batteries are type D, Mono, R20P , R20PU or LR20.

Step 4 Close the covers in the reverse of the order of step 2.



Caution

- When batteries are consumed mostly, the battery mark  is displayed.
- Replace batteries with four new ones, when  is displayed.
- Do not mix used and new batteries. Do not use batteries of different type and manufacturer.
Doing so may cause damage to the batteries and the scale.
- Check the battery direction. If the batteries are installed in the wrong direction, it may cause battery leakage. If the direction of just one battery is wrong, the scale may work temporarily.
- The battery life depends on the ambient temperature. It becomes shorter in low temperatures such as in winter.
- Remove the batteries from the display unit, when the scale is not to be used for a long time.
Leaving them installed may result in leakage and cause damage.
- Damage due to battery leakage is not covered under warranty.

5. Cautions

5.1. Precautions for Installing the Indicator

DANGER

- Do not install the product in a location exposed to corrosive gas or combustible gas.

Consider the following installation conditions to ensure that the scale can operate properly.

- The ideal installation environment has a stable temperature and humidity, a robust and flat floor surface, is not exposed to wind or subject to vibration, is an indoor location not exposed to direct sunlight, and has a stable power supply.
- Do not install the product on a soft floor or a location subject to vibration.
- Do not install the product in a location exposed to wind or subject to dramatic changes in temperature.
- Avoid locations exposed to direct sunlight.
- Do not install the product in a location subject to strong magnetism or strong electromagnetic waves.
- Do not install the product in a location prone to electrostatic. When the humidity is 45% RH or less, rubbing an insulating material such as plastic will easily build up an electrostatic charge.
- This product is not waterproof. Use the optional display cover or another item to ensure that the display does not get wet.
- When using an AC adapter, an unstable AC power supply may cause malfunction.
- 30 minutes before use, connect the power supply (AC adapter or batteries) and press the **ON/OFF** key to turn the display on.
- The scale is for indoor use only. If it is used outside, this product may receive a lightning surge that exceeds its discharge capacity. If that happens, this product may be damaged because it cannot withstand the energy of the lightning.


For other precautions, cautions regarding the assembled scale, storage, and cleaning, visit the A&D website <https://www.aandd.jp> to view [Instruction manual for the HV-C/CP and HW-C/CP series]

Read "Precautions" on (<https://aandd.jp/products/weighing/scale/platform/hvw-ccp.html>).


5.2. Load Cell Connection

The load cell can be connected with a 6-wire or 4-wire connection.

We recommend connecting using the 6-wire configuration for optimum accuracy and stability.




1	SIG -
2	SIG +
3	EXC -
4	SEN -
5	SEN +
6	EXC +
7	SHLD



Terminal	Terminal Function	
1	SIG-	Load cell input -
2	SIG+	Load cell input +
3	EXC-	Load cell power -
4	SEN-	Sense input -
5	SEN+	Sense input +
6	EXC+	Load cell power +
7	SHIELD	Shield


Load cell



(A) 6-wire load cell connection (recommended)

Cable

Cable



(B) 4-wire load cell connection

Method	Advantage	Disadvantage	Remark
6-wire configuration (recommended)	Less error even if the length of load cell cable is long or a thin load cell cable is used. Less error even if multiple load cells are used.	Slightly complicated to wire.	When using a summing box, it is strongly recommended wiring be done with the 6-wire configuration.
4-wire configuration	Easy to wire.	The accuracy of temperature counting is affected by resistance of the conductor wire for the load cell cable.	Using a long load cell cable or multiple load cells tends to cause error.

Precautions for connecting with the 4-wire configuration

Make sure to do the following when connecting with the 4-wire configuration.

- Short-circuit between EXC+ and SEN+, and between EXC- and SEN-.
- When using a long a load cell cable, use one with a cross-sectional area that is as large as possible. Also, use a cable that is as short as possible.

Ref.: Connection examples of connecting to the SCB series, Dust & Waterproof Precision Weighing Platform (with the 4-wire configuration)


Load cell terminal number	Color of cable core for the SCB series	Function of terminals for SCB series
1	Blue	Signal – (Output terminal)
2	Green	Signal + (Output terminal)
3, 4	White	Excitation – (Input terminal)
5, 6	Red	Excitation + (Input terminal)
7	Yellow	Shield

5.3. How to Connect the Load Cell

1. Refer to “[5.2. Load Cell Connection](#)”, and connect the cable core to the terminal block of the load cell.
 - ❑ Hold down the white button on each terminal in the terminal block of the load cell when connecting or disconnecting the wire. (Additional tool is not required.)

Connect or disconnect the wire while pressing the white button

2. Once the load cell is connected, make sure that wiring has been done correctly.



5.4. Verifying Load Cell Output and Input Sensitivity

The input sensitivity is 0.1 μ V/division or more.

When designing a weighing scale, the following calculation formula should be satisfied.

- The input sensitivity requires a change in output voltage, from the weighing device, to change the display value as a one digit step. In order to achieve a scale with stable performance, select the input sensitivity as large as possible.

Calculating formula:

$$0.2 \leq \frac{E \times B \times d}{A \times n}$$

A: Rated capacity of load cell

B: Rated output (mV/V)

d: Minimum division

E: Excitation voltage (mV) = 5000 mV

n: Number of load cells

Example of calculation:

In the case of designing a scale with a capacity of 60 kg and minimum division of 0.005 kg, using one load cell with a rated capacity of 100 kg and rated output of 1 mV/V:

Rated capacity of Load cell:

A = 100 kg

Rated output:

B = 1 mV/V

$$\frac{5000 \times 1 \times 0.005}{100 \times 1} = 0.25 > 0.2$$

Minimum division:

d = 0.005 kg

Excitation voltage:


E = 5000 mV

The above indicates there is no problem with this design.

Number of load cells:

n = 1


5.5. Setting Up the Indicator



Connect the included AC adapter to a power source.

- Make sure that the power source you are using is correct before connecting to it.
For HW-D-C, you can also use four D-cell batteries (R20P / R20PU / LR20).

⚠ If you are using the unit in a location where static electricity is likely to occur, be sure to also fasten an earth wire to the earth terminal (M3 screw).



5.6. Sensitivity Adjustment and Parameter Settings


When connecting to a load cell (weighing platform), sensitivity adjustment needs to be performed.

For details, refer to "[7. Sensitivity Adjustment](#)".


As needed, configure the function settings. For details, refer to "[8. Setting Functions](#)".

6. Part Names

<HW-D-C (battery-powered model)>




<HW-D-CP (for built-in printer models)>






6.1. Display and Symbols

Display





Display/Symbol	Description
STABLE	Stable mark Lit when the measured value is stable and in a state suitable for being read.
NET ZERO	Zero point mark The zero point is the reference point for the scale. When the ZERO key is pressed with nothing on the weighing pan, zero (the zero point) is displayed as the measured value.
NET ZERO	Tare deducted mark Displayed when the TARE key is pressed to deduct the tare. Use this to deduct the weight of objects that will not be weighed, such as containers.
► PT	Preset tare deduction mark Flashes when a digitally input tare value is displayed.
► HOLD	Hold mark The display is being held.
► M+	Total function mark Displayed when using the total function.
	C type battery level mark Displayed when the voltage of the batteries has dropped. Replace the batteries with four new D size batteries.
	Comparator function display When using the comparator function, displays the result of comparing with the set upper limit value and lower limit value.
Measured mass STABLE ZERO	An example of the zero point (example scale reference point). Displays the zero point mark. Displays the stable mark. Displayed by pressing the ZERO key with nothing on the weighing pan.
Unit of mass 	

Display/Symbol	Description
Counting unit 	An example of the counting mode display. By registering a unit mass in advance, you can count the number of objects on the weighing pan.
No load 20 samples 	An example of registering a unit mass for the counting mode. 20 samples are used to register the unit mass. "No load" means that there are no countable objects on the weighing pan.
10 samples Load 	An example of registering a unit mass for the counting mode. 10 samples are used to register the unit mass. "-" means that there is something on the weighing pan.

- For details on operation and each function, please refer to [Instruction Manual: HV-C/CP, HW-C/CP Series] on the A&D website at <https://www.aandd.jp>.

6.2. Description of Keys

Key	Description
	<ul style="list-style-type: none"> Power key Turns the power of the display ON or OFF. When the display is turned ON, the internal circuits are powered. When the display is turned OFF, only the minimum required power to have the scale in standby and the power consumed by the AC adapter connected to the power outlet are consumed.
	<ul style="list-style-type: none"> Zero key If you press the ZERO key with the measured value stabilized within $\pm 2\%$ of the zero point taken when the power was turned ON ("power on zero"), that point is set as the zero point, zero is displayed, and the zero point mark is lit. If a tare is being deducted, the tare is cleared. When displaying the total result, the total count and total value are cleared.
	<p>Tare deduction key If you press the TARE key with a positive measured value stabilized, the mass on the weighing pan is deducted as the mass of the container (tare). Zero is displayed, and both the zero point mark and tare deducted mark are lit (tare deduction). If the container (tare) is removed from the weighing pan while the tare is being deducted to return to the zero point, both the zero point mark and tare deducted mark are lit. In this case, a negative tare value is displayed.</p> <p>Note</p> <ul style="list-style-type: none"> The measurement range is reduced by the tare mass.

Key	Description
	Adds to the total.
	SET key Select +/- when setting the upper and lower limits.
 TARE pressed with 	Enters the mode for setting the preset tare deduction.
 pressed with 	Feeds the paper of the built-in printer.
 pressed with 	Displays the total result.
 pressed with 	Sets the upper and lower limit values for the comparator.
 pressed with 	Proceeds to the operation for registering a unit mass in the counting mode.
	MODE key <ul style="list-style-type: none"> <input type="checkbox"/> Switches the display mode (unit). Weight ⇔ Count <input type="checkbox"/> When setting values, functions as the key for selecting the item to set.
	HOLD key Holds the display. Refer to the internal settings.
	PRINT key Prints or outputs data for the displayed value. The operation depends on the internal settings.
 Display OFF pressed with 	Enters the internal settings.

7. Sensitivity Adjustment

- The description of sensitivity adjustment in this manual is different from that in the instruction manual for the HV-C / CP and HW-C / CP series. Please read the description below.

7.1. Sensitivity Adjustment Items


Sensitivity adjustment mode has the following three functions.

- Setting of the weighing capacity, minimum division, and decimal point position.
- Sensitivity adjustment using a weight
- Correcting for gravitational acceleration


Enter the sensitivity adjustment mode in the following way.

1. Confirm that the scale(indicator) is in weighing mode
(display shows measurement unit).


2. Remove the protective cover from the four screws of the load cell panel on the rear of the display unit, and then loosen the four screws and open the load cell panel.



3. Press the CAL switch to display **CALSET**
(Then go to “7.2. Setting of the Weighing Capacity / Minimum Division / Decimal Point Position”, “7.3. Sensitivity Adjustment Using a Weight”, or “7.4. Correcting for Gravitational Acceleration”)



- Relations between items in sensitivity adjustment mode and key operations are shown in the diagram below.



Note: Use the **MODE** key to select the item to execute, and then execute with the **TARE** key.

Note: To end sensitivity adjustment mode, press the **ZERO** key or CAL switch.

The display turns off. (You can also turn it off using the **ON/OFF** switches.)

7.2. Setting of the Weighing Capacity / Minimum Division / Decimal Point Position

Set the weighing capacity, minimum division, and decimal point position. Be sure to perform these setting first when connecting to a load cell (base unit). The indicator does not require setting each time, if nothing is to be changed.

1. Refer to “[7.1. Sensitivity Adjustment Items](#)”, to enter the calibration mode. The indicator displays **CALSET**.
2. Press the **ENTER** key to enter the setting mode of the weighing capacity, minimum division, and decimal point position.
3. The indicator displays the currently set minimum division and calibration unit.

(Display example: **d - 1 kg**)

The blinking digit indicates the minimum division. Press the

SET key to select 1, 2, 5.

The unit indicates the sensitivity adjustment unit.

Press the **MODE** key to select either “kg” or “lb”.

Press the **ENTER** key to store the currently set minimum division and calibration unit, and proceed to the next step.

4. After displaying **CAP**, the indicator displays the currently set weighing capacity and decimal point position.
(Display example: **060000 kg**)

Set the weighing capacity and decimal point position using the following keys:

Numeric keypad Setting the weighing capacity.

SET Shift the decimal point position.


Press the **ENTER** key to store the currently displayed weighing capacity and decimal point position, and proceed to the next step.

Note: Press the C key to revert to the previous value.

- ❑ Available setting range of the resolution is 60,000 or less.
The resolution is the value that divides the weighing capacity by the minimum division. (Decimal point position is ignored.)

5. After displaying **End**, the indicator displays **CALSET** and the setting is complete.

- ❑ After setting the weighing capacity, minimum division, and decimal point position, be sure to perform “[7.3. Sensitivity Adjustment Using a Weight](#)”.



7.3. Sensitivity Adjustment Using a Weight

This function adjusts the scale (indicator) for accurate weighing.

Sensitivity adjustment must be done when the HW-D-C is initially connected to a load cell (base unit) or the combination is changed.


Sensitivity adjustment may also be required according the changes in the environment.

- When the scale (indicator) is initially installed.
- When the scale (indicator) is moved to a location far away.
- When the ambient environment has greatly changed.
- In periodic sensitivity adjustment.

Note

- Prepare a weight. (A weight equivalent to the weighing capacity of the scale to be adjusted is recommended. However, the value for the weight can be set (changed).)**

1. Turn on the scale and supply it with power for 30 minutes or longer.
 - Change the parameter for the internal settings item **[P_{OFF}]** or place something on the weighing pan to keep the automatic power off function from activating.
2. Refer to “[7.1. Sensitivity Adjustment Items](#)”. **[CALSET]** is displayed when you enter sensitivity adjustment mode.
3. Press the **MODE** key to display **[CAL]**.
4. Press the **ENTER** key to display **[CAL 0]**.
Make sure there is nothing on the weighing pan and wait for the stability indicator to light up.
5. Press the **ENTER** key to save the zero point on the scale and display the value for the weight.
 - The value for the weight is the same as the weighing capacity. (Initial state)
 - To adjust just the zero point, turn off the scale to end without performing step 6.
6. To adjust with a weight value different than the weighing capacity, change the value with the numeric keypad.
* Press the C key to revert to the previous value.
 - A weight equivalent to the weighing capacity of the scale is ordinarily used. If using a different weight, it should be at least 2/3 the weighing capacity.
7. Place on the weighing pan a weight of the value displayed. Wait for the stability indicator to light up.
8. Press the **ENTER** key to end sensitivity adjustment. **[End]** will be displayed. After displaying **[CAL]**, the setting is complete.
9. To end setting, press the CAL key. The display turns off.



Note

- If the scale (indicator) is moved to a distant location after sensitivity adjustment, adjust the gravitational acceleration value to that of the area where it will be adjusted next. Then adjust the scale. See the next chapter for setting gravitational acceleration.

7.4. Correcting for Gravitational Acceleration

When relocating a scale (indicator), you need to perform sensitivity adjustment with a weight. If a weight is not available, you can adjust the scale (indicator) by correcting the gravitational acceleration. Refer to the acceleration map on the last page, and change the gravitational acceleration value recorded in the scale (indicator) to the one for appropriate location.

Note

- If sensitivity adjustment is done using a weight at the place where the scale (indicator) is used, it does not need to be corrected for gravitational acceleration.


1. Refer to "7.1. Sensitivity Adjustment Items". **CAL SET** is displayed when you enter sensitivity adjustment mode.

CAL SET MODE
Press twice

2. Press the **MODE** key twice to display the gravitational acceleration parameter (Example: "9.7985").

9.7985

3. Press the **ENTER** key to enter the gravitational acceleration setting mode.

9.7985
ENTER
← Press

4. To adjust the gravitational acceleration value displayed, change the value with the numeric keypad.

* Press the C key to revert to the previous value.

9.7985
Numeric
keypad

5. Press the **ENTER** key to display **End** and save the parameter. After displaying the gravitational acceleration parameter (Example: "9.7985"), the setting is complete.

9.7985
ENTER
←

6. To adjust using a weight, return to step 2 of "7.3. Sensitivity Adjustment Using a Weight". To end setting, press the CAL key. The display turns off.


End
9.7985

8. Setting Functions

The indicator has CF function settings to specify the indicator performance.

After installing the indicator, the indicator does not require resetting or changing of this CF function as far as it is used normally.

8.1. Setting of the CF Function



1. Refer to "7.1. Sensitivity Adjustment Items", to enter the sensitivity adjustment mode. The indicator displays

CALSEE

CALSEE

MODE Press 3 times

2. Press the **MODE** key three times to display **CF**.

CF

ENTER Press twice

3. Press the **ENTER** key to display the setting item. Press the **ENTER** key again and the setting value will start blinking.

CF 6 2

Press (Select) MODE Numeric keypad

4. Select the setting item and parameter using the following keys:

MODE Proceed to next setting item.

Numeric keypad Change the blinking digit

ENTER Press

5. Press the **ENTER** key to stop the blinking and record the setting.

6. If you want to adjust the sensitivity using a weight, proceed to step 2 of "7.3. Sensitivity Adjustment Using a Weight". To end the setup, press the **ZERO** key, and after **CF** is displayed, press the **CAL** key.

The display turns off.

8.2. CF Function List

Item	Parameter	Description	
Used internally [CF 1]	-	Not available for setting change	
Used internally [CF 2]	-	Not available for setting change	
Used internally [CF 3]	-	Not available for setting change	
Used internally [CF 4]	-	Not available for setting change	
Used internally [CF 5]	-	Not available for setting change	
Zero tracking width / time [CF 6]	0 1 ◆ 2 3	No zero tracking 0.5 d/0.5 seconds 0.5 d/1.0 seconds 0.5 d/1.5 seconds	Zero tracking: Function to track the zero point and keep the display at zero. When the setting value is 0, the internal settings t_{rc} (zero tracking), $St-b$ (stability detection width), and $St-t$ (stability detection time) cannot be changed and the setting items are not displayed.
Zero point mark when net weight is zero during taring [CF 7]	0 ◆ 1	Not available Available	
Push zero range [CF 8]	◆ 0 1	±2% Unlimited	The percentage of the weighing capacity that can be set to zero when the ZERO key is pressed.
Power on zero range [CF 9]	0 1 ◆ 2 3 4	0% (Do not power on to zero) ±10% ±50% ±100% Unlimited	Percentage of the weighing capacity that can be set to zero when powered on.
Power on Tare [CF 10]	0 ◆ 1	Not available Available	Taring is done when power is turned on. (power on zero takes priority)
Clear tare by zero operation [CF 11]	0 ◆ 1	Not available Available	
Tare [CF 12]	0 ◆ 1	Tare the weight at the indicated scale interval Tare at the internal count	
Used internally [CF 13]	-	Not available for setting change	

Item	Parameter	Description	
Decimal point display selection CF 14	◆ 0	Select with internal settings <i>Pnt</i>	
	1	Dot	
	2	Comma	
Used internally CF 15	-	Not available for setting change	
Hold function CF 16	0	Not available	A function that freezes the weighing value when the HOLD key is pressed.
	◆ 1	Available	
Preset Tare CF 17	0	Not available	
	◆ 1	Available	
Used internally CF 18	-	Not available for setting change	
Used internally CF 19	-	Not available for setting change	
Used internally CF 20	-	Not available for setting change	
Used internally CF 21	-	Not available for setting change	
Used internally CF 22	-	Not available for setting change	
Used internally CF 23	-	Not available for setting change	
Zero tracking, response characteristics, and stability detection function display CF 24	0	Not available	When the setting value is 0 or 2, the internal settings <i>trc</i> (zero tracking), <i>St-b</i> (stability detection width), <i>St-t</i> (stability detection time), and <i>End</i> (response characteristics) cannot be changed and the setting items are not displayed.
	◆ 1	Available	
	2	Not available Center zero mark does not light up when total weight is zero after taring.	
Saving zero value and tare weight CF 25	◆ 0	Do not save	Zero and tare values are stored even when the power is turned off.
	1	Save	
Used internally CF 26	-	Not available for setting change	

◆: Factory settings d = minimum division

The settings are not changeable for **CF 1** to **5**, **13**, **15**, **18** to **22** or **26**.

9. Options

9.1. Installing Options

Option name	Contents
HVW-02CB	USB interface
HVW-03C	RS-232C interface
HVW-04C	Comparator relay output/buzzer/contact input
HVW-27C	<i>Bluetooth</i> ® interface
HVW-11C	Wall mounting bracket

Refer to the optional instruction manual for details.

Installation example


OP-ch1 : HVW-03C

OP-ch2 : HVW-02CB

OP-ch3 : HVW-04C

OP-ch2

Example of HVW-02CB



OP-ch3

Example of HVW-04C

OP-ch1

Example of HVW-03C

10. Maintenance

- Refer to "5. Cautions" regarding use.
- Refer to "10.3. Error Code Table" and corresponding mode for displayed error code.
- Refer to "7. Sensitivity Adjustment" regarding precision weighing.
- Periodically check the accuracy of weighing. Adjust the scale (indicator), if it is moved to another location or the environment has changed.

10.1. Repair

Do not disassemble/assemble the product without an authorized service engineer. Doing so may cause an electric shock or damage to the product. In this case, repair is not covered under warranty. Contact your local A&D dealer if the product needs service or repair.

10.2. Error Display

In this situation	Confirm these items
Product does not turn on. Nothing displayed.	<input type="checkbox"/> Is the power turned ON properly? <input type="checkbox"/> Are the batteries exhausted? <input type="checkbox"/> Are you using the correct AC adapter?
The product does not display zero at first.	<input type="checkbox"/> Check whether something is touching the weighing pan. Remove any objects from the weighing pan. <input type="checkbox"/> Perform zero point calibration for the scale.
----- is displayed.	<input type="checkbox"/> This error is displayed if the measured value is unstable when the power is turned ON. Avoid wind and vibration. Check whether something is touching the weighing pan. <input type="checkbox"/> Is the load cell cable correctly connected inside the display? <input type="checkbox"/> This error is displayed if zero cannot be displayed when the display is turned ON. Remove any objects from the weighing pan. <input type="checkbox"/> Perform zero point calibration for the scale.
[-]RL E is displayed.	<input type="checkbox"/> This error is displayed during sensitivity adjustment. Check whether the weighing pan is attached properly and whether the weight is too heavy, and try again.
-[-]RL E is displayed.	<input type="checkbox"/> This error is displayed during sensitivity adjustment. Check whether the weighing pan is attached properly and whether the weight is too light, and try again.
E is displayed.	<input type="checkbox"/> The load is too heavy. Remove objects from the weighing pan.
-E is displayed.	<input type="checkbox"/> The measured value is too low. Check whether the weighing pan is attached properly.
The displayed value does not change.	<input type="checkbox"/> Is the hold function enabled? Change Hold in the internal settings. <input type="checkbox"/> Turn the power OFF.
Lb O is displayed.	<input type="checkbox"/> The voltage of the batteries is low. Replace the batteries with new batteries.
Lb I is displayed.	<input type="checkbox"/> The output voltage of the AC adapter is low. Check whether you are using an AC adapter with the correct specifications.

10.3. Error Code Table

When any of the following errors are displayed, try turning the display off and on again.

<i>Err 1</i> is displayed	<input type="checkbox"/> Mass sensor is failed.
<i>Err 2</i> is displayed	<input type="checkbox"/> Temperature sensor is failed.
<i>Err 3</i> is displayed	<input type="checkbox"/> Memory (circuit) is failed.

11. Specifications


11.1. Specifications List

Specifications are subject to change without notice.

Input sensitivity	0.2 μ V/d min. (d is the minimum scale interval)		
Input signal range	-16 mV to 16 mV		
Load cell excitation voltage	5 V \pm 10%		
Load cell drive capacity	350 Ω \times 4 maximum		
Temperature coefficient zero	\pm 0.02 μ V/ $^{\circ}$ C typ. \pm 0.1 μ V/ $^{\circ}$ C max.		
Temperature coefficient span	\pm 3 ppm/ $^{\circ}$ C typ. \pm 15 ppm/ $^{\circ}$ C max.		
Linearity	\pm 0.01% of full scale		
Maximum display resolution	60,000		
Display	Backlit seven segment LCD display with text height of 26 mm Three color five level comparator LED		
Display update	Approx. 10 times/sec.		
Power supply	HW-D-C	AC adapter	Confirm that the AC adapter matches the voltage and plug type of your region. An AC adapter is not provided in some regions. 50 Hz/60 Hz
		Batteries	Size D (R20P/R20PU/LR20) \times 4
	HW-D-CP	AC adapter	Confirm that the AC adapter matches the voltage and plug type of your region. An AC adapter is not provided in some regions. 50 Hz/60 Hz
Battery life (HW-D-C)		Load cell \times 1 (1 k Ω)	Approx. 1,200 hours
		Load cell \times 1 (350 Ω)	Approx. 600 hours
		Load cell \times 4 (350 Ω \times 4)	Approx. 200 hours
Operating environment		-10 $^{\circ}$ C to 40 $^{\circ}$ C 85% RH or lower (without condensation)	
Dimensions	HW-D-C	255 mm (W) \times 99 mm (D) \times 160 mm (H)	
	HW-D-CP	255 mm (W) \times 111 mm (D) \times 160 mm (H)	
Weight (approximately)	HW-D-C	0.8 kg	
	HW-D-CP	1.0 kg	


11.2. Dimensions

HW-D-C



Unit: mm


HW-D-CP



Unit: mm

11.3. Gravity Acceleration Map

Amsterdam	9.813 m/s ²	Manila	9.784 m/s ²
Athens	9.800 m/s ²	Melbourne	9.800 m/s ²
Auckland, NZ	9.799 m/s ²	Mexico	9.779 m/s ²
Bangkok	9.783 m/s ²	Milan	9.806 m/s ²
Birmingham	9.813 m/s ²	New York	9.802 m/s ²
Brussels	9.811 m/s ²	Oslo	9.819 m/s ²
Buenos Aires	9.797 m/s ²	Ottawa	9.806 m/s ²
Calcutta	9.788 m/s ²	Paris	9.809 m/s ²
Chicago	9.803 m/s ²	Rio de Janeiro	9.788 m/s ²
Copenhagen	9.815 m/s ²	Rome	9.803 m/s ²
Cyprus	9.797 m/s ²	San Francisco	9.800 m/s ²
Djakarta	9.781 m/s ²	Singapore	9.781 m/s ²
Frankfurt	9.810 m/s ²	Stockholm	9.818 m/s ²
Glasgow	9.816 m/s ²	Sydney	9.797 m/s ²
Havana	9.788 m/s ²	Tainan	9.788 m/s ²
Helsinki	9.819 m/s ²	Taipei	9.790 m/s ²
Kuwait	9.793 m/s ²	Tokyo	9.798 m/s ²
Lisbon	9.801 m/s ²	Vancouver, BC	9.809 m/s ²
London (Greenwich)	9.812 m/s ²	Washington, DC	9.801 m/s ²
Los Angeles	9.796 m/s ²	Wellington, NZ	9.803 m/s ²
Madrid	9.800 m/s ²	Zurich	9.807 m/s ²



MEMO

THIS PAGE INTENTIONALLY LEFT BLANK.



A&D Company, Limited

3-23-14 Higashi-Ikebukuro, Toshima-ku, Tokyo 170-0013, JAPAN
Telephone: [81] (3) 5391-6132 Fax: [81] (3) 5391-1566

A&D ENGINEERING, INC.

Headquarters Office: 4622 Runway Boulevard, Ann Arbor, Michigan 48108, U.S.A.
Sales Office: 47747 Warm Springs Boulevard, Fremont, California 94539, U.S.A.
Tel: [1] (800) 726-3364 Weighing Support: [1] (888) 726-5931 Inspection Support: [1] (855) 332-8815

A&D INSTRUMENTS LIMITED

Unit 24/26 Blacklands Way, Abingdon Business Park, Abingdon, Oxfordshire OX14 1DY United Kingdom
Telephone: [44] (1235) 550420 Fax: [44] (1235) 550485

A&D AUSTRALASIA PTY LTD

32 Dew Street, Thebarton, South Australia 5031, AUSTRALIA
Telephone: [61] (8) 8301-8100 Fax: [61] (8) 8352-7409

A&D KOREA Limited

서울특별시 영등포구 국제금융로6길33 (여의도동) 맨하탄빌딩 817 우편 번호 07331
(817, Manhattan Bldg., 33. Gukjegeumyung-ro 6-gil, Yeongdeungpo-gu, Seoul, 07331 Korea)
전화: [82] (2) 780-4101 팩스: [82] (2) 782-4264

ООО A&D RUS

Почтовый адрес: 121357, Российская Федерация, г. Москва, ул. Верейская, дом 17
Юридический адрес: 117545, Российская Федерация, г. Москва, ул. Дорожная, д.3, корп.6, комн. 86
(121357, Russian Federation, Moscow, Vereyskaya Street 17)
тел.: [7] (495) 937-33-44 факс: [7] (495) 937-55-66

A&D Instruments India Private Limited

D-48, उद्योग विहार, फेस -5, गुडगांव - 122016, हरियाणा, भारत
(D-48, Udyog Vihar, Phase-V, Gurgaon - 122016, Haryana, India)
फोन : [91] (124) 4715555 फैक्स : [91] (124) 4715599

A&D SCIENTECH TAIWAN LIMITED.

台灣台北市中山區南京東路 2 段 206 號 11 樓之 2
(11F-2, No.206, Sec.2, Nanjing E.Rd., Zhongshan Dist., Taipei City 10489, Taiwan, R.O.C.)
Tel : [886](02) 2322-4722 Fax : [886](02) 2392-1794

A&D INSTRUMENTS (THAILAND) LIMITED

บริษัท เอ แอนด์ ดี อินส్ట્રુમેન્ટ્સ (ไทยแลนด์) จำกัด
168/16 หมู่ที่ 1 ตำบลรังสิต อำเภอธัญบุรี จังหวัดปทุมธานี 12110 ประเทศไทย
(168/16 Moo 1, Rangsit, Thanyaburi, Pathumthani 12110 Thailand)
Tel : [66] 20038911