


ダストプレートの設置方向

CORRECT DIRECTION TO INSTALL THE DUST PLATE (BM/GH/HR-i Series)


UP
↑



断面図/Cross section

正 CORRECT

UP
↑



断面図/Cross section

誤 WRONG