LCCU-21 USB Connection Instructions

A&D Company, Limited

❶ Connecting LCCU-21 to PC by USB cable

Device Installation

USB Cable

PC Side USBA Male

LCCU-21 Side USB Micro B Male

① Connect the LCCU-21 and PC with the supplied USB cable

② A software installation message will appear shortly as shown below

Device Setup

Installing device...

Please wait while Setup installs necessary files on your system. This may take several minutes.

Close

What to do if the COM Port is not known

①Open the control panel window and click device manager

②Expand the COM LPT Port option to reveal USB Serial Port (COM). The number after COM is the port number

▷ 🖰 Mice and other pointing devices
▷ 🖵 Monitors
▷ 🖳 Network adapters
▲ 🖷 Ports (COM & LPT)
    🖷 USB Serial Port (COM3)
▷ 🖶 Print queues
▷ 🖳 Processors

What to do if drivers were not installed automatically

①Access the following link http://www.ftdichip.com/FTDrivers.htm
②Press click here

▶ **Drivers**

PLEASE NOTE - When updating drivers, refer to the following document: AN_107 - Advanced Driver Options

New drivers are now available to support the FT4222H - for D2XX drivers please click here.

③Select setup executable and download

Windows*	2017-03-10	2.12.26	2.12.26	-	-	-	WHQL Certified. Includes VCP and D2XX. Available as a setup executable Please read the Release Notes and Installation Guides.

④After downloading CDM v2.12.26 WHQL Certified.exe click the file and install

Note: When CDM v2.12.26 WHQL Certified.exe is updated the version number, 2.12.26, will change