

# RA23-125 Touch Panel Sheet—Instruction Manual

Touch Panel Sheet

**Notice:**  
You may feel some resistance when you insert touch panel sheet along the LCD display.

(1)  
Face glossy side of touch panel sheet to LCD and position it as above.

(2)  
Toward direction of above, insert touch panel sheet between LCD surface and cushioning behind chassis.  
Notice: Direction to insert the lower right corner is different as shown at (3).

(3)  
Keep inserting the panel to direction shown above.

(4)  
If touch panel was positioned as shown above, insert the top left corner and adjust as (5).  
Notice: Insert right half of the panel deep enough so that there is space on top left corner.

(5)  
Turn and adjust position of touch panel sheet.

Check space.

